

## DEAR CUSTOMER, THANK YOU FOR PURCHASING OUR PRODUCT!

### MAIN BUTTONS

- Button for monitoring / switching on / off the screen (top button):
- Long press to turn the unit on/off.
  - Short press to switch on/off the main screen.
  - Measurement - camera
  - Bottom button - return to main menu
  - Left side - SIM card input

### CHARGING INSTRUCTIONS

This product uses magnetic charging. Connect the charging cradle to the USB input and the other end to the rear charging pins of your device. Once connected, charging will start automatically and the charging icon will appear on the screen. The required input voltage is 5V1A or 5V2A.

A full charge usually takes 2 hours. Do not use the device while it is charging.  
Note: Do not connect the magnetic charging cable to 2 contacts at the same time with conductive material, as this may cause a short circuit.

### SPORTS FUNCTION

- running outdoors
- walking
- running
- cycling
- basketball
- football
- table tennis
- badminton
- skipping

### WATCH OPERATION

- Slide down the watch's main interface to access GPS brightness, Wi-Fi, aeroplane mode and Do Not Disturb mode.
- Slide up to access pedometer, music and cloud controls
- Slide right on the watch interface to access push notifications
- Slide left on the watch interface to open the main menu, then sports modes.

### MAIN SCREEN

To change the appearance of the Home screen, hold it down for 2 seconds, then select a control. Once you've made your selection, tap it briefly to select it.  
The watch has 18 dials to choose from and you can customise it to your liking.

### PRECAUTIONS

1. Weak battery:  
If the battery is discharged, charge the device immediately to protect its life.
2. Charging:  
Do not use the watch while charging.
3. Ambient temperature above 50 degrees Celsius during charging may cause overheating, deformation and burning of the device.
4. Do not swim, dive or use the device under water.
5. The device uses a built-in battery and must not be disassembled separately.
6. Avoid contact with eyes and skin in case of battery rupture and leakage.

### MAIN MENU

- Telephone  
Enter a number from the list and press the dial icon to dial the number.
- Contact  
Make sure your watch is paired properly with your phone so you can add and delete contacts.
- Messages
- Setting
- Pulse  
Put the watch on your wrist before starting the heart rate monitoring function. To measure your heart rate, your wrist must be very close to the watch. The value will be displayed after ten seconds.
- Blood oxygen  
You must first put the watch on your wrist before measuring your blood oxygen concentration. Then click to enter the blood oxygen detection process. The value will be displayed after 10 seconds. Blood oxygen will be actively measured every hour.
- Sleep  
Before going to bed, put on your watch and measure the quality of your sleep. The default time is 21:00-9:00.

### DEVICE PARAMETERS

Display: 1.39" IPS  
Screen resolution: 454 x 454 dpi  
Water resistance: IP67  
Sensor: 3-axis G-sensor  
Battery capacity: 500 mAh  
Synchronisation: Bluetooth 5.0  
Package Content: Charging cable, User manual, WLT10 smartwatch  
Device compatibility: iOS 11 + Android 5.1 or later

### IMPORTANT INFORMATION

- 1.Safety:  
-Clean watches with a soft cloth to keep them clean (use clean water or sea water)
- 2.Water resistance notes (even if it is a waterproof watch):  
Beware of the following methods as they will deteriorate the waterproofing.  
-Do not wear the watch in the shower.  
-Do not wear the watch in a heated swimming pool, sauna or other place with high temperature and humidity.

- Breath measurement  
Click Start and follow the instructions for inhaling and exhaling.
- Internet
- Camera
- Gallery
- Calendar
- Alarm
- Music  
You can play, pause, and rewind songs;  
Tap the volume icon to adjust the volume;  
Songs can be played randomly or in repeat mode,  
To add music, connect the watch to your computer using a USB cable.
- To record sound  
Tap the icon to start recording, tap again to stop recording, save and delete options will be displayed, access the list of recorded files and choose whether to play or delete the current recording.
- File manager  
Click Manage Files to view the currently available memory, click again to manage, view, create and edit.

- Weather  
Insert your SIM card and switch on your mobile network to update your local weather information.
- Traffic
- Desktop settings  
Dashboard settings include knob selection, menu style and toggle style
- System optimisation
- Watch Store
- App Store
- Assistant  
When connected to a mobile phone, users can enjoy remote photography, music control, mobile search and more.
- Google Play
- Google Maps

-Do not wear the watch while washing your hands or face, or while working in areas where soap or detergents are used. Wash salt or dirt off the watch after immersion in the sea.

### WARRANTY

1. Under normal use, provided that the product is not mechanically defective and has not been caused by misuse, consumers can benefit from free warranty service for 24 months from the date of purchase.
2. Consumers cannot benefit from the warranty if:  
A. the damage is self-inflicted,  
B. the warranty period has expired,  
C. they have not used the product in accordance with the instructions for use and maintenance,  
D. the products have been disassembled, repaired by themselves or immersed in water.



**www.watchmark.com**  
**ul. Paprotna 7**  
**Wrocław**  
**POLAND**

## SMARTWATCH WATCHMARK WLT10

### User manual



**watchmark.com**