

EN

## DEAR CUSTOMER, THANK YOU FOR PURCHASING OUR PRODUCT!

Please read the entire instruction manual carefully before use. It is recommended to use only the original battery, charger and accessories supplied with the device.

Neither the manufacturer nor the distributor is responsible for the use of third party accessories.

(The features listed in this manual may vary slightly from model to model, as the manual is a general description of the SmartWatch and some models may differ from the standard SmartWatch).

The device must be charged for at least 2 hours before first use.

You must download and install the app and accept all permissions before using the device,

otherwise all functions will not be available.

The company reserves the right to change the contents of this manual.

### LOADING INSTRUCTIONS

Charge your watch using the charger included in the kit. The watch will start automatically while charging.

### ACTIVATION

Android phone users can download the app by searching for "TEFITI" in the Google Play store. iOS users can download the app from the AppStore.

Open the "TEFITI" app -> Settings -> Bluetooth -> Search for "Smart Device" and connect.

If the Bluetooth icon on the watch is blue, it means there's a connection, while red means there's no connection.

The device is compatible with the following devices:

iOS 9.0 and higher and Android 4.4 and higher. To use the GPS

feature, you need a device running Android 6.0. You must connect your Watch to the app before using it for the first time.

Once connected, the Watch automatically syncs the time. After

you launch the app, you need to configure your personal

information.

### ON/OFF

To start the clock, press and hold the side button for 3 seconds.

To turn off the clock, also press and hold the side button for 3 seconds.

### MAIN SCREEN

You have a choice of 6 controllers, which you can set at will.

### FUNCTIONS

1. The home screen displays: battery level, date and time (date and time synchronise if the smartphone is connected via Bluetooth) and steps.

2. Pedometer. The pedometer is activated for 24 hours. At

midnight, the data is saved and reset to 0 so that it can be

recalculated.

3. Calorie counter.

4. Distance travelled.

5. Enter the heart rate interface and start measuring. The heart

rate measurement is dynamic and stops when the interface is

exited; the heart rate measurement function is for daily training

only and not for medical purposes.

6. Blood pressure measurement: Go to the Blood Pressure menu

and take one blood pressure measurement (data is stored in real

time in the app).

7. Blood Oxygen Measurement: enter the Blood Oxygen menu

and take one blood oxygen measurement. (The data is stored in

real time in the app).

8. Sleep quality monitoring: daily sleep quality measurement.

9. sports modes: press and hold to open the function. 7 sports

modes are available.

### PRECAUTIONS

1. Weak battery: If the battery is low, charge the device immediately to preserve its life.

2. Charging: do not use the watch while it is charging.

3. Ambient temperature above 50°C during charging may

cause overheating, deformation and burn the device.

4. Do not swim, dive or use equipment underwater.

5. The device operates on a built-in battery and must not

be disassembled by the user.

6. Avoid contact with eyes and skin in case the battery

becomes damaged and leaks.

### IMPORTANT INFORMATION

1.Safety:

-Clean the watch and strap with a soft cloth (use clean water or sea water).

- Make sure the lens of the watch is close to your skin to

measure your heart rate.

- The skin temperature on your wrist is too low due to the

weather, which affects the heart rate monitoring.

2. Notes on water resistance (even if it is a waterproof watch):

Be careful with the following methods as they affect water

resistance.

-Do not wear the watch under the shower.

## SMARTWATCH WATCHMARK WE3



### Instructions for use

-Do not wear the watch in a heated swimming pool, sauna or other environment with high temperature or humidity.

-Do not wear the watch while washing your hands or face, or while performing any activity that involves the use of soap or detergent.

-When immersed in the sea, the watch should be cleaned of salt and dirt.

### WARRANTY

Warranty service:

1. Under normal use of the products, as long as the product has no mechanical damage and has not been caused by improper use, consumers are entitled to free warranty service for 24 months from the date of purchase.

2. Consumers are not entitled to warranty service if:

A. The damage was self-inflicted,

B. the warranty period has expired,

C. they have not used the product in accordance with the

instructions for use and maintenance,

D. the products have been disassembled, repaired or immersed in

water.