DEAR CUSTOMER, THANK YOU FOR PURCHASING OUR PRODUCT!

EN

You should read the entire instruction manual carefully before starting to use it. It is recommended to use only the original battery, charger and accessories that are included in the kit supplied with the device.
The manufacturer and distributor are not responsible for the use of third party accessories.
(The functions listed in this manual may vary slightly between models as the manual is a general description of the smartwatch, some models may deviate from the standard).
The device should be charged for at least 2 hours before first use.
Before using the device, you must download the app, install it and accept all permissions, otherwise all functions will not be available.
The company reserves the right to change the contents of this manual.

CHARGING INSTRUCTIONS

Charge the watch using the appropriate charger included in the kit. The watch will start automatically while charging.

ACTIVATION

Download and install the SMART TIME PRO app so your watch can sync data from the app. The app allows you to set goals, analyze data and much more.
The SMART TIME app works with iOS 8.0 and Android 4.4.

FUNCTIONS

1. Switch the knob
On the watch's homepage, long-press to open the different dials, then swipe to select the desired dial.

2. High speed key switch
Slide the dial to enter the high-speed key interface, you can set BT3.0, volume, language, background, settings, vibration, lumianans, gestures, theme, alarm, clock and airplane mode.

3. Heart rate
Pressing the down button on the home page will quickly take you to the heart rate interface. Or you can check your heart rate in menu -> Heart Rate.Wear your watch the right way. Open the heart rate function on the watch and measure manually.

4.Sport modes
If you want to enter sports mode, just slide the watch face to the right, you can also enter it from the main menu -> Sports Mode. The smart watch supports various sports, for example: indoor running, outdoor running, cycling, climbing, marathon and many more.

5.Pedometer
By swiping your finger up, you can check the number of steps, heart rate, calories and distance for the current day. Or you can check heart rate in main menu -> pedometer.

6. Ringing
The Sport version only supports Bluetooth connectivity, instead of connecting via SIM card there are two versions of phone call support: : after a successful Bluetooth 3.0 connection is established, the watch will automatically sound a voice or you can switch the phone to answer a call or dial a number by using the following method

7. Sleep monitor
The watch monitors your sleep when you wear it. After syncing your sleep data with the app, you can check your sleep details in the app.

8. Remote sensing
This feature allows you to remotely control the mobile camera and take photos

9. Sedentary lifestyle
Sitting for too long is not good for your health. You can set a time on your watch or app to remind you to get moving.

PARAMETERS

Wrist length: 271 mm (including dial)
Wrist width: 22 mm
Weight: 66 g
Battery: 320 mAh lithium polymer
1.3-inch display
Controls: touch screen
Bluetooth: 3.0 and 4.0
Waterproof: IP67 (waterproof, only during daily activities. It is waterproof when it rains or you wash your hands. Don't wear it when washing the car, swimming, diving or showering.

MEASUREMENTS

1.Low battery
In case of low battery, you should charge the device immediately to protect the battery life.
2.Charging:
Do not use the watch while it is charging.
3.Ambient temperature during charging above 50 degrees C may lead to overheating, deformation and burning of the device.
4.Do not swim, dive or use the device underwater.
5. The device uses a built-in battery and is not allowed to be disassembled separately.
6. If the battery breaks and leaks, avoid contact with eyes and skin.

IMPORTANT INFORMATION

1.Protection:
-Rinse the watch with a soft cloth to keep it and the strap clean. (use clean water or sea water)
-Make sure the heart rate lens on the watch is close to the skin
-The temperature of the skin on the wrist is too low due to the weather, which affects the heart rate control.
2.Waterproof notes (even if it is a waterproof watch):
The following methods should be noted as they weaken the waterproofness.
-Don't wear your watch in the shower.
-Do not wear the watch in an insulated pool, sauna or other high temperature/humidity environment.
-Don't wear the watch when you wash your hands or face with soap or detergent at work.
-Wash off any salt or dirt from the watch when immersed in the sea.

WARRANTY

Warranty service:
1. Under normal use of products, as long as the product has no mechanical damage and has not been caused by misuse,24 months from the date of purchase, consumers can avail of free warranty service.
2. Consumers cannot take advantage of the warranty if:
A. the damage is self-inflicted,
B. the warranty period has expired,
C. they have not used the product in accordance with the instructions for use and maintenance,
D. the products have been disassembled, self-repaired or immersed in water.

SMARTWATCH M5

User manual