

SMARTWATCH WATCHMARK G1



Instrucțiuni de utilizare Instructions for use

EN

DEAR CUSTOMER, THANK YOU FOR PURCHASING OUR PRODUCT!

Please read the complete instructions carefully before use. It is recommended to use only the original battery, charger and accessories included with the device.

Neither the manufacturer nor the distributor is responsible for the use of third-party accessories.

(The features mentioned in this manual may vary slightly between models as the manual is a general description of a smartwatch, some models may differ from the standard).

Before first use, the device must be charged for at least 2 hours.

Before using the device, you must download the app, install the app and accept all permissions, otherwise all functions will not be available.

The company reserves the right to change the contents of this manual.

APLICACION

1. Scan the QR code with your mobile phone on the watch display (Settings-App Download), then install the GloryFit app. You can also install the GloryFit app from your mobile phone's app store.

2. After activating Bluetooth and installing the app, open and log in to GloryFit, then select (G1 device to add) on the devices page and connect to it.

3. If the watch doesn't connect to the app, find the settings on the watch, then press 'reset'. Then try to connect to the app again.

Important: for the watch to pair correctly with your phone, it must be connected directly from the app level with bluetooth enabled and not in the settings on your phone.

TOUCH FUNCTIONS

1. Open the control panel: scroll the screen in the main interface from top to bottom

2. Open Messaging/Notifications: swipe the screen in the main interface from bottom to top.

3. Open Main Menu: swipe your finger on the screen through the main menu

from left to right (Note: on other interfaces, swipe left to right to return to the previous interface). This allows you to select sport and monitor watch functions such as: heart rate control, status, sleep, stopwatch, messages, settings.

5. Status interface: swipe the screen from right to left to read the current measurement (e.g. step count, heart rate, kcal)

6. Change the appearance of the dial: press and hold the main interface screen for 3 seconds, the watch will vibrate; you can then swipe left or right to select the dial.

7. Power on: turn on by pressing and holding the power button for 5 seconds

8. Quick Sports Pause/Continue: press the power button.

9. Press the power button to return to the start page. if you are on the second level of the interface, you will return to the first level).

FUNCTION

1. Sports

- There are 13 sports modes (running, walking, cycling, climbing, yoga, jumping, tennis, baseball, basketball, badminton, football, rugby, table tennis)
- For running, walking, climbing and other sports modes, you can click on the screen to view sports data (steps, pace, calories, distance and duration).

2.Heart Rate Monitor: The watch will continuously monitor your heart rate for 24 hours (you need to enable "Heart Rate Monitor" in APP first), you can also view historical heart rate data in APP.

Note: When this function is enabled, power consumption will increase and battery life will be reduced.

3. Sleep: The watch will keep track of your sleep status from 18:00 to 23:59 the next day. Note: The sleep data on your watch will be deleted every day at 18:00, but you can still check your sleep history in the RunTo Sport app.

4.Music: The watch can be used to control your mobile phone's music player, it can be used to play/pause or skip songs (it is only compatible with your mobile phone's built-in music player, it may not be compatible with a third-party player and you cannot adjust the volume on the watch

5. Stopwatch: the watch can be used to count time

6. Message: The watch will receive and display SMS/messages/social network notifications from your phone.

7. Settings: You can turn off or reset your watch, as well as check the watch information and download the app's QR code.

CHARGING

1. Place the watch on the magnetic charger, ensure that the charging contacts on the back of the watch are fully absorbed by the metal contacts of the charger.

2. Connect the charging cable to a standard USB charger.

MEASUREMENTS

1. Weak battery:

In the event of a weak battery, charge the device immediately to protect battery life.

2. Charging:

Do not use the watch while it is charging.

3. Ambient temperature during charging above 50 degrees Celsius can lead to overheating, deformation and burning of the device.

4. Please do not swim, dive or use the device underwater.

5. The device uses a built-in battery and it is forbidden to take it apart yourself.

6. Avoid contact with eyes and skin in case of battery rupture or loss.

IMPORTANT INFORMATION

1.Protection:

- Wipe the watch with a soft cloth to keep the watch and strap clean. (use clean water or sea water)

- Make sure the heart rate lens on the watch is close to your skin - the temperature of the skin on your wrist is too low due to the weather, which will affect your heart rate control.

2. Notes on water resistance (even if it is a waterproof watch): Be careful with the following methods as they will deteriorate the waterproofing.

-Please do not wear the watch in the shower.

-Do not wear the watch in a heated swimming pool, sauna or other high temperature/humidity environment.

-Do not wear the watch when washing your hands or face, at work where soap or detergent is used.

-After diving into the sea, be sure to wash off any salt or dirt from the watch.

PARAMETR

Display: Touch screen display

Bluetooth: BT5.0

Housing material: Zinc alloy with vacuum

Belt material: silicone rubber

Battery: 285 mAh lithium polymer battery

Battery and battery life: Standby > 30 days Working time: 7 days (all functions active)

Button: side power button

Charging mode: Magnetic charging IP68 waterproof rating

GUARANTEE

Warranty Service:

1. Under normal product use, unless the product has gross damage

caused by misuse, 24 months from the date of purchase, consumers can take advantage of the free warranty service.

2. Consumers may not benefit from the guarantee if:

A. they have caused the damage themselves,

B. the warranty period has expired,

C. they have not used the product in accordance with the instructions for use and maintenance,

D. the products have been disassembled, repaired by themselves

or immersed in water.