

## DEAR CUSTOMER, THANK YOU FOR YOUR PURCHASE OUR PRODUCT!

You should read the entire instruction manual carefully before starting to use it. It is recommended to use only the original battery, charger and accessories included in the kit supplied with the device.

The manufacturer and distributor are not responsible for the use of accessories from other manufacturers.

(The functions listed in this manual may vary slightly between models as the manual is a general description of the smartwatch and some models may deviate from the standard).

The device must be charged for at least 2 hours before first use.

Before using the device, you must download the app, install it and accept all permissions, otherwise not all functions will be available.

The company reserves the right to change the content of this manual.



www.watchmark.com  
ul. Paprotna 7  
Wrocław  
POLAND

## EXPLANATION OF BUTTONS

Physical button:

- Long on/off button.
- Short on/off button turns on/off the main screen.
- Short press the main function selected to return to the picture.



Top button (rear):

-Allows you to return to previous functions in the main menu

Bottom button (scroll)

-Allows you to move to other functions in the main menu

## FUN

- Music - Play music remotely. Switch to music playback, move the screen to the left and select "Music." The clock should connect to an app on your mobile phone.

- Games - There are two games in the smartwatch. To select one of them, swipe the screen to the right and press in the middle of the screen and select the "Game" icon. There are two games: "Young Bird" and "2048".

-Camera - to access the camera remote control, slide the screen to the right and select the shutter function. Smart Watch must be connected to a mobile phone via an app.




## CHARGING INSTRUCTIONS

This product uses magnetic charging.

Connect the charging pad to the USB input and the other end to the rear charging contacts of the device. Once the connection is established, charging starts automatically and the charging icon appears on the display.

A full charge usually takes 2 hours. Do not use the device while it is charging.

Note: Do not connect the magnetic charging cable to two contacts at the same time with conductive material as a short circuit may occur.



## MAIN FUNCTIONS

- Pedometer
- Distance travelled
- Calorie consumption measurement
- Sleep monitor
- 12 sports modes
- Pressure measurement
- Blood oxygenation measurement
- Heart rate measurement
- Incoming call information
- Incoming alert information (WeChat, QQ, Facebook, Line, WhatsApp, KakaoTalk, etc.)
- Weather
- Camera remote control
- Music remote control
- Find My Phone function
- Games
- Ringtones

## APPLICATIONS

Download the DaFit app, use a specific store or QR code.



Once the app is installed, turn on Bluetooth on your phone and open the installed app. Confirm any consents and other permissions you need. Enter your personal details in the registration form.

To connect your watch, select "Add" and then select our device. Your phone will search for a Bluetooth device and select the correct model (K28H).

## HARDWARE REQUIREMENTS

iOS 8.0 and later  
Android 5.1 and later  
Bluetooth 5.0 supported



## DEVICE PARAMETERS

Display: 1.32-inch IPS  
Display resolution: 360x360 dpi  
Waterproof: IP67  
Sensor: VC31  
Battery capacity: 360 mAh  
Sync: Bluetooth 5.0  
Package contents: charging cable, user manual in Polish, WAK28 H smartwatch  
Device compatibility: iOS8.2 + Android 4.4 and later

## GENERAL SETTINGS

Scroll down the screen to access the general settings for your device.

The date, day of the week and temperature are displayed.

-To answer a call, select the handset icon so that it lights up blue (first from the left).

-Clock information and the option to change the menu layout are also available

-Now you can turn off the vibration, select the brightness of the screen and enter the general settings of the device (reset, etc.).

## MAIN INTERFACE

To change the appearance of the main screen, hold it for 2 seconds, then you can dial the number you want to call. Once you've selected it, tap it quickly to select it.

The watch has 24 dials, and you can select additional dials in a separate app.



## SPORTS MODE



The smartwatch includes several sports modes. To select a sports mode, swipe right on the screen, select the workout icon and click it in the middle of the screen. The smartwatch has sports modes such as: walking, jogging, cycling, ski jumping, badminton, basketball, football, trail running, climbing, golf, rowing, home workout, gym workout. To exit sports mode, move the screen to the left.

## HEALTH FUNCTIONS

The watch has the following health functions:

- Pulse measurement: to measure, move the screen and select the HR icon, click the centre of the screen and wait a few seconds before taking a measurement.

- Blood oxygenation. On the screen on the right, click SPO2. Wait about 5 seconds before taking the measurement.

- Blood pressure, temperature measurement, scroll to the right and select the RR icon, then wait about 5 seconds before taking the measurement.



## SMARTWATCH WATCHMARK G-WEAR

### Manual instruction



watchmark.com

## IMPORTANT INFORMATION

1. Protection:

-Wipe the ears with a soft cloth to keep them clean (use clean water or sea water)

2. Notes on water resistance (even if it is a waterproof watch): Be careful with the following methods as they deteriorate the waterproofing.

-Do not wear the watch in the shower.

-Do not wear the watch in a heated swimming pool, sauna or other high temperature/humidity environment.

Do not wear the watch when washing your hands or face or when working where soap or detergent is used.-When immersed in the sea, rinse off any salt or dirt from the watch.

## WARRANTY

Warranty service:

1. Under normal use of the products, provided that the product is free from mechanical damage and is not the result of improper use, consumers can benefit from free warranty services for 24 months from the date of purchase.

2. Consumers cannot benefit from the warranty if:

- A. self-inflicted damage,
- B. the warranty period has expired,
- C. the product has not been used in accordance with the instructions for use and maintenance,
- D. the products have been disassembled, self-repaired or immersed in water.