

IMPORTANT

1.Charge your watch.

2.Install the dedicated app for your chosen smartwatch model on your smartphone

3) Switch on your phone's Bluetooth (do not search for your watch at this stage)

4) Open the app and search for your smartwatch from within the app

After a successful search, connect the smartwatch to your phone (connection instructions are in the APPLICATION section)

DEAR CUSTOMER, THANK YOU FOR PURCHASING OUR PRODUCT!

Please read the entire user manual carefully before use. It is recommended to use only the original battery, charger and accessories that come with the device.

Neither the manufacturer nor distributor is responsible for the use of third party accessories.

(The functions shown in this manual may vary slightly from model to model, as the manual is a general description of the smartwatch, some models may deviate from the standard).

Please charge the device for no less than 2 hours before using it for the first time. Before using the device you must download the application, install the application and accept all authorisations, otherwise not all functions will be available. The company reserves the right to change the content of this manual.

- Swimming

Your swimming time will be calculated automatically. The watch counts the number of laps in the pool. In swim mode, the touch screen is locked. To stop and view your training data, press the BACK button. To return press the OK button.

- History

This is where you will find all the activity for that month. To view older data, slide the screen up. Tap the screen for detailed information.

- Sport settings

This is where you set data such as target value, reminders, units of measurement, personal data, etc. Slide up the screen to view more

FAQ

1.How long does it take to connect to the satellite? Two hours or more the first time. When the satellite is connected the search time is two minutes.

2. Satellite connectivity problem

If you have problems with GPS connectivity, follow the steps below:

- do not move while searching for connectivity

BASIC INFORMATION

Charging

- Charge your watch using the charger supplied.
- To connect the charger, connect the cable to the charging contacts on the underside of the watch.

Do not use the watch while it is charging. It will take approximately 70 minutes to fully charge the watch. Once charged, the watch will start automatically.

NOTE: Do not connect the magnetic charging cable to two contacts at the same time with conductive material. It may cause a short circuit.

Switching the watch on/off

- To start the watch hold down the bottom BACK button for 3 seconds
- To turn the watch off hold down the same button for 3 seconds.

APPLICATION

Before first use, connect your watch to the app.

After a successful connection, the watch will automatically synchronise the time.

After starting the app, configure your personal data.

Download the FunDo application:

- Android users at Google Play
- iOS users in AppStore

Open FunDo application -> settings -> Bluetooth -> search for SPORT_LE and connect.



The connection is active when the Bluetooth icon on the watch is yellow, while grey means no connection.

The device is compatible with:

iOS 9.0 and later and Android 4.4 and later.

To use the GPS function you will need an Android 6.0 device.

MAIN SCREEN

- Main dials

Choose from three main dials showing date, time, battery level, steps taken, and calories burned. To change the home dial, touch the screen.

- Shortcuts

There are four icons in the shortcut menu: sound/vibration, app QR code, screen exposure, Bluetooth. To access the shortcuts slide the screen down.

- Functions

To view the following functions: Steps, Sleep, Pulse, Stopwatch, Compass slide the screen up.

- Notifications

After connecting your device to the FunDo mobile application, notifications coming from your phone will be displayed on the watch. To access the notification screen slide the screen to the right.

- in case of battery swelling DO NOT puncture

- in case of battery rupture and leakage

avoid contact with eyes and skin

- do not disassemble by yourself (the device uses a built-in battery)

- in case of battery damage, contact your local waste disposal department

IMPORTANT INFORMATION

- Notes on measurement

NOTE: The heart rate measurement function is not precise, so it cannot be used for medical diagnosis. Measurement error:

- make sure that the watch is properly worn and fits tightly against the skin before taking a measurement

- When measuring outdoors, weather conditions and low temperatures may affect the accuracy of the measurement.

PARAMETERS

Display: 1.3" 240x240

Satellite: GPS + Baidou

Water resistance: IP68

Heart rate measurement: Optical

Bluetooth: 4.0

Sensor: Compass

- Sport

To switch to sport mode slide the screen to the left. The watch has ten sport modes: outdoor walking, treadmill walking, cycling, outdoor running, treadmill running, trekking, swimming, basketball, table tennis, badminton, football. At the very end, history and settings are displayed. To view modes, scroll up the screen.

- Main menu

To display the main menu, go to the sports section and scroll left. In the menu you will find language settings, screen brightness, Bluetooth name, locator and device information.

BASIC FUNCTIONS

- Pedometer.

At midnight the data is saved and reset to zero for re-counting. The pedometer dial also displays the distance covered in kilometres and the percentage of the set goal. To view the weekly summary slide the screen to the left.

- Sleep

The sleep function displays the total time we slept and the time when our sleep was Deep and Light. To view a weekly summary slide the screen to the left.

- Heart rate measurement:

To start the measurement bring the watch close to your hand and touch the screen. To save the measurement history, touch the screen again. The heart rate function is for home use only and is NOT a medical diagnosis.

- Stopwatch

To start the stopwatch touch the screen. To stop touch the screen again.

- Compass

Before first use, move the watch following the pattern shown on the screen to calibrate the device.

SPORTS FUNCTIONS

- Modes using GPS connection:

Outdoor Walking (OutWalk), Outdoor Running (OutWalk), Jogging, Trekking

Accelerometer/Gyroscope: 3axis, 3D

Acceleration

Battery: 430mAh

System Compatibility: Android 4.3+, IOS 8+

Weight: 71g

Size: 52/40/14,5mm

Input: 3.7V 1.0A MAX

Implementation standard: LX10328-2018

WARRANTY

Warranty service:

1. Under normal use of the products, if the product has no mechanical damage and caused by misuse, 24 months from the date of purchase, consumers can take advantage of the free warranty service.

2. Consumers cannot benefit from the warranty if:

A. they have done the damage themselves,

B. the warranty period has expired,

C. they have not used the product in accordance with the instructions for use and maintenance,

D. they have dismantled, repaired or immersed themselves in water.

The training time will be calculated automatically when a GPS connection is obtained.

GPS connection:

- static icon - connected

- flashing icon - in connection

- no icon - not connected

To view your route, average heart rate and more data, swipe the screen to the right. To pause and temporarily stop the sport mode, swipe left.

To exit the workout and save data press BACK and touch the END screen.

- Modes that do not require a GPS connection:

Walking on treadmill, Running on treadmill, Cycling Basketball, Table tennis, Badminton, Football

Workout time will be calculated automatically.

Move the screen to the right to see your average heart rate and more data.

To pause and temporarily stop the sport mode swipe left.

To exit the workout and save data, press BACK and touch the END screen.

SMARTWATCH WATCHMARK WS929

Manual instruction



watchmark.com



www.watchmark.com
ul. Paprotna 7
Wrocław
POLAND