



## SMARTWATCH WL13

User manual

### DEAR CUSTOMER, THANK YOU FOR PURCHASING OUR PRODUCT!

EN

Please read the full instructions carefully before use. It is recommended to use only the original battery, charger and accessories included with the device.

The manufacturer and distributor are not responsible for the use of accessories from other manufacturers.


(The functions listed in this manual may vary slightly between models as the manual is a general description of the smartwatch and some models may differ from the standard).

The device must be charged for at least 2 hours before first use.

Before using the device, you must download the app, install it and accept all permissions, otherwise not all functions will be available.

The Company reserves the right to change the contents of this manual.

### CHARGING INSTRUCTIONS



This product uses magnetic charging.

Connect the charger to the USB input and to the rear charging contacts of the device. Once the connection is established, charging starts automatically and the charging icon appears on the display.

Note: Do not connect the magnetic charging cable to two contacts at the same time with conductive material as a short circuit may occur.

### HARDWARE REQUIREMENTS

iOS 9.0 and later

Android 4.4 and later

Bluetooth 4.0 supported

You must have an Android

6.0 device to use the GPS

function.



Android 4.4 +



iOS 9.0 +

### ACTIVATION

Turn on the Bluetooth function on your phone. Go to Bluetooth settings and select **L13** to connect your smartwatch to your phone. Your phone displays the pairing information and you confirm the pairing. When the device is positively connected, the Bluetooth label on the smartwatch turns blue and you can receive and make calls.

IMPORTANT: Only contacts from your SIM card will be visible on the watch, and the contact name will be visible when you receive a call.

You can also connect your WL13 smartwatch to your phone via the dedicated "MActive" app. This combination will allow you to store your measurements and activity data, and allow you to set goals and various notifications.



### ON/OFF

Hold the bottom button for 3 seconds to start the clock.

To turn the clock off, hold down the bottom button for 3 seconds.

### CLOCK FACES

There are 5 clock faces that can be set as you like.

### FUNCTIONS

1. Pedometer. Step counting lasts 24 hours. At midnight, the data is stored and reset to 0 so that it can be recalculated.
  2. Calorie counter.
  3. Distance travelled.
  4. Heart rate.
- The heart rate test is dynamic and stops when you leave the interface.
5. Blood pressure measurement.
  6. Blood Oxygenation measurement.

7. ECG measurements can only be taken in the app. The history is automatically saved.
8. Sleep quality monitoring.
9. Activity.
10. Remote control of the phone camera.
11. Remote control of music playback on your phone.
12. Phone search (this function is available when connected to the MActive app).
13. You can adjust the brightness of the screen.
14. Alarm.
15. Stopwatch
16. Calendar
17. Calculator
18. Sedentary mode: when set, indicates that you are not moving for too long.

### DATE AND TIME SETTING

When your device is connected to the app, the date and time are synchronised.

You can also set the data manually. Enter a setting - clock - and turn synchronisation off. Then go to the date and time and set them manually.

### PRECAUTIONS

1. Weak battery;

If the battery is low, charge the device immediately to protect the battery life.

2. Charging;

Do not use the watch while it is charging.

3. Do not use the watch while it is charging as described above.

50 degrees Celsius can cause overheating, deformation and burning of the device.

4. Do not swim, dive or use the device under water.

5. The device uses a built-in battery and it is forbidden to disassemble it separately.

6. In case of battery rupture and leakage, avoid contact with eyes and skin.

### IMPORTANT INFORMATION

1. Security;

-wipe the watch with a soft cloth to keep the watch and strap clean (use clean water or seawater).

- Make sure the heart rate lens on the watch is close to your skin.

- The skin temperature on the wrist is too low due to weather conditions, which affects the heart rate control.

2. Notes on water resistance (even if it's a water-resistant watch):

Be aware of the following methods as they deteriorate the waterproofing.

-Do not wear the watch in the shower.

-Do not wear the watch in a heated swimming pool, sauna or other high temperature/humidity environment.

-Do not wear the watch when washing your hands or face or when working where soap or detergent is used.

-Remember to wash any salt or dirt off the watch when you immerse it in the sea.

### WARRANTY

Warranty service:

1. For 24 months from the date of purchase, consumers can take advantage of free warranty services during normal use of the products, provided that the product is free from mechanical damage and is not the result of improper use.

2. Consumers cannot benefit from the warranty if:

A. the damage is self-inflicted,

B. the warranty period has expired,

C. they have not used the product in accordance with the instructions for use and maintenance,

D. the products have been disassembled, self-repaired or immersed in water.