




Product description

Package includes:
- Wi12 watch - instructions
- Magnetic charging cable



1. Long press: switch on/off
2. Short press to enter and return to menu
3. Press twice to change menu appearance
4. Turn the Rotary encoder to scroll through pages, select start-up screen, etc.

ACTIVATION

Scan the code and download the free "Wearfit Pro" app.



1. Download the "WearFit PRO" app to your mobile phone and install it. You can search for it directly in the App Store or scan the QR code above.
2. Connect your watch:
 - Scan the code: After turning on your watch and navigating to the watch face page, swipe up to go to the settings function, then click the "Scan connection with code" shortcut button. A link will appear with a QR code that you can scan directly into your Wearfit Pro device.

- Manual connection: With Bluetooth enabled on your mobile phone, open the app and search for your device.
- Connect and make a call via Bluetooth. When the watch is in the initial state, Bluetooth is disabled for calls, so you cannot use the call and music controls. To open the local menu, scroll down the watch screen and highlight the handset icon with the Bluetooth apostrophe. When enabled, a Bluetooth connection can be found on your mobile phone (if Bluetooth is enabled). Once connected, you can use music playback and call functions.

Watch interface instructions

1. Swipe right or left on the touchscreen to select the clock home screen. Swipe left on the Dialer page to access Smart Components.
2. On the Dialer application page, swipe left to access Smart Components. The system consists of 3 components.
3. Press the button briefly to display the menu. Then quickly double-click the button to change the appearance of the menu. There are three types of menus. To return to the home page, press the button briefly.
4. Click the icon of any application on the menu page to access that function, swipe right to return, and press the side button to return to the dialer home page.
5. You can scroll through the menu by sliding your finger across the touch screen or by rotating the side button.

Functions

1. Today's event: daily step counter, calories burned and distance covered.
2. Sport modes: walking, running, treadmill running, cycling, mountain climbing, swimming and record of records done.
3. Heart rate: to measure your heart rate click on the heart rate function and after 2 seconds it will be measured automatically
4. Sleep monitor: the watch will track your sleep the moment you wear it. You can check your sleep details in the app after syncing your sleep data with the app.
5. QR code: open the app and click "Device", select "your device", select your model and then scan the QR code, if the connection sign is blue it means the device has been paired.

6. Alarm clock: you can set the alarm directly in the watch. It is necessary to set the alarm time and you can set the repeatability of the alarm on particular days.
7. Messages: after connecting your watch to your phone, you will be able to receive text messages on your smartwatch (memory for 8 messages)
8. Compass: click on the compass function to start the program. Follow the instructions on the page to calibrate the compass. After successful calibration, the current orientation value is automatically displayed.
9. Music: after successfully pairing your smartwatch with your phone, you can control the music playing on your phone with your watch.

10. Stopwatch: click on the stopwatch function and then start to start the countdown, you can stop the time and then resume, or reset.
11. Find Phone: When pressed, the phone will ring or vibrate.
12. settings:
 - App code: scan the code to download an app to your phone.
 - photos: remote control the phone's camera
 - information: you will find information about the model and serial number
 - turn off: hold the screen for 3 seconds to turn off the watch
13. Lock screen: to lock the screen, swipe down on the main screen and you will see the icon "Lock screen". Click on it to lock the screen. To unlock the screen, hold down the bottom physical button for 3 seconds.

WATCHMARK

www.watchmark.com
ul. Paprotna 7
Wrocław
POLAND

Pulse - the watch has the ability to continuously monitor your pulse for 24 hours and adjust its value according to your mood:

- 1 to 29 - relaxed
- 30 to 59 - normal
- 60 to 79 - medium
- from 80 to 99 - high.

Settings - watch brightness, fixed time, phone settings, watch brightening by wrist movement, do not disturb mode, sound and vibration, voice switching, phone connection, password, watch information, restart, factory settings, shutdown.

Touch the contacts of the magnetic watch charging cable.
After successful connection, the charging symbol will appear on the display.

Charging



Caution!

1. Do not charge the device in a damp place.
2. Make sure that the metal contacts on the watch case and the magnetic charging cable are not dirty.
3. Clean the metal contacts on the back of the watch and the charging cable regularly with a clean cloth. To ensure proper charging, ensure that the charging cable fully touches the watch contacts.
4. For safety reasons, use your computer's USB port for charging or choose a power supply with an output of 5V 1A or less.

Data transmission via Bluetooth

When the watch is connected to a mobile phone, it immediately syncs some data from the phone via Bluetooth, including weather, alerts, health data, etc. When disconnected, data is not synchronised.

PRECAUTIONS

1. The measurement results of this product are for information purposes only and not for medical use.
2. This product is waterproof according to IP67 and must not be used in contact with water.
3. Some functions vary depending on the software version.
4. Do not swim, dive or operate the device under water.
5. The device uses a built-in battery and must not be disassembled.
6. Avoid contact with eyes and skin in case of battery rupture and leakage.

IMPORTANT INFORMATION

1. Protection:
 - Clean the watch with a soft cloth to keep the watch and strap clean (use clean water or sea water).
 - Make sure the lens of your heart rate watch is close to your skin.
 - the skin temperature on your wrist is too low due to weather conditions, which affects your heart rate.
2. Notes on water resistance (even if it is a waterproof watch):
 - Pay attention to the following methods as they affect water resistance.
 - Do not wear your watch in the shower.
 - Do not wear the watch in a heated swimming pool, sauna or other areas of high temperature and humidity.

WARRANTY

Warranty service:

1. Under normal use of the products, as long as the product has no mechanical damage and has not been caused by misuse, consumers can enjoy free warranty service for 24 months from the date of purchase.
2. Consumers cannot claim under the warranty if:
 - A. They caused the damage themselves,
 - B. the warranty period has expired,
 - C. they have not used the product in accordance with the instructions for use and maintenance,
 - D. the products have been disassembled, repaired by themselves or immersed in water.

Smartwatch Wi12



User Manual